



Manual for Cabrio Tent

Parts included:

2x bolt M5x25mm

2x bolt M5x35mm

2x elastic strap

4x ring M5, 4x parker,

4x nut M5,

2x push button bracket,

2x plastic nut M5,

2x Strap holder.



Drill a hole 5,5 mm on 600 mm from the front of the box and 25 mm from the edge.

Check if the distance between the bars is 560 mm wide.

During transport it is possible that the bar is a little out of shape. Push or pull the bar in shape to avoid stress on the box.

Mount the M5 x 25mm bolts on the side of the box. (for aluminum box M5x35mm). First 1 ring on the bolt, then mount from inside out, then 1 ring and then 2 nuts. Tighten these 2 nuts against each other.





Make sure the bolt can turn in the box. Mount the tent on the bolts with the plastic M5 nuts on the end.

Mount the 2 push button brackets on the front to mount the tent. With the aluminum box the hole has to be drilled first.

Mount two strap holders on the rear of the box.



Take care: Do not use the cabrio tent below 0 degree. The transparent windows can break easily at this temperature. The warranty will be void.



Beware: On the bike there is a cap on the headset, tightened with a small screw, this can damage the tent when it is folded. Tip: put this bolt side wards, then the damage will be avoided.